





# HYBRID BD+HDD Camcorder

Introducing the world's first Blu-ray Disc Camcorder, the DZ-BD7HE is the next generation in Full HD 1920 x 1080 camcorder featuring compatibility with Blu-ray Disc, the next generation Full HD optical disc. Blu-ray Disc enables 1 hour of Full HD recording and delivers truly incredible image quality.

Additional features include seamless, end-to-end Full HD processing from capture, image processing to output plus Hybrid BD+HDD technology; shoot 4 hours of Full HD to hard disk drive, edit then burn at the touch of one button to multiple Blu-ray Discs to share or archive for future viewing – all without a PC!







## **HYBRID** CAMCORDER HDE

## Seamless, end-to-end Full HD Process













**DZ-BD7HE** Technical Specifications

### KEY FEATURES

- Blu-ray Disc for 1 hour of Full HD recording 
   Photo capture from BD/HDD/DVD • Full HD 1920 x 1080 end-to-end process
- SD Card Slot · High capacity 30GB Hard disc drive USB 2.0 Connectivity
  - Interactive guide function
  - 10x Optical Zoom Lens
  - 2.7" 16:9 display screen

#### HDMI connectivity 1-Second Quick Start

5.3 Megapixel CMOS Sensor

PICTURE MASTER Full HD Processing

CAMERA	
Lens type	HD quality multi coated lens
LCD	2.7" (16:9 Widescreen) (210k Pixels)
EVF	Colour (200k Pixels)
Optical/Digital zoom CMOS Image Sensor (Pixels)	10x/500x Total 5.3M, Movie 2.07 M, Still 4.32M
CMOS Size	1/2.8"
Lens F No.	F1.8 (Wide) – 3.0 (Tele)
Focal length	f 5.0-50mm
Filter diameter	43mm
LCD Video light	•
Built-in flash Accessory shoe	• (cold)
EIS (Electronic Image Stabilisation)	
Minimum illumination	24 Lux (Auto, Shutter Speed 1/30)
Focus	Auto/Manual
White balance	Auto/Set/Outdoor/Indoor/Halogen
Iris Recording coope modes	Auto/Manual Auto/Portrait/Contlight/Surf & Spaw/Law Light
Recording scene modes	Auto/Portrait/Spotlight/Surf & Snow/Low Light
RECORDING CAPACITY	
Recording Media HDD BD	30GB HDD (Embedded)
DVD	8cm BD-RE/-R 8cm DVD-RAM/-RW/-R/+RW
Movie Formats/Recording Times	Maximum recording time (HDD)
	HX: 4hrs./HF: 5.3hrs./HS: 8hrs.
	Maximum recording time (BD)
	HX: 1hr./HF: 1.3hrs./HS: 2hrs.
	Maximum recording time (DVD) SX: 20min./SF: 30min.
	5A. 201111./51 . 3011111.
HDD TO DVD BURNING FUNCTION	
Compatible Optical Disc media One touch dubbing button	BD-R/BD-RE/DVD-RAM/-RW/-R/+RW
2x Speed dubbing	•
Dubbing modes	New/Date/Select/All
GENERAL	
Audio Format	2ch Stereo Dolby Digital
Still Image (Picture size)	2400 x 1800 (4.32 Mega-pixels)
DCF	•
DCF Photo capture Movie to JPEG from HDD and	2400 x 1800 (4.32 Mega-pixels) • • (1920 x 1080)/(640 x 360)
DCF Photo capture Movie to JPEG from HDD and BD/DVD	• (1920 x 1080)/(640 x 360)
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time	•
DCF Photo capture Movie to JPEG from HDD and BD/DVD	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*)
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/•
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/-
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button	• (1920 × 1080)/(640 × 360) 1-Second Quick Start (1 sec*) •/-
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/-
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/-
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/- SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions PC software	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) -/- SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD)	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/- -/- SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows 100min (HDD)
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD)	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/- SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows 100min (HDD) 5.7W (HDD)
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/- -/- SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows 100min (HDD)
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/- SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows 100min (HDD) 5.7W (HDD) DZ-BP14S
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/- SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows 100min (HDD) 5.7W (HDD)
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES Battery pack AC adaptor USB PC Cable	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) -/- SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows 100min (HDD) 5.7W (HDD) DZ-BP14S Li-ion 1360mAh
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES Battery pack AC adaptor USB PC Cable HDMI Cable	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/- SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows 100min (HDD) 5.7W (HDD) DZ-BP14S Li-ion 1380mAh AC adaptor/charger
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES Battery pack AC adaptor USB PC Cable HDMI Cable PC software	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/- -/- SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows 100min (HDD) 5.7W (HDD) DZ-BP14S Li-ion 1360mAh AC adaptor/charger
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES Battery pack AC adaptor USB PC Cable HDMI Cable PC software Shoulder strap	• (1920 x 1080)/(640 x 360) 1-Second Quick Start (1 sec*) •/- SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows 100min (HDD) 5.7W (HDD) DZ-BP14S Li-ion 1380mAh AC adaptor/charger
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES Battery pack AC adaptor USB PC Cable HDMI Cable PC software	<ul> <li>(1920 x 1080)/(640 x 360)</li> <li>1-Second Quick Start (1 sec*)</li> <li>-/-</li> <li>SD</li> <li>English/French/Spanish/Italy/German/Chinese</li> <li>White/Wipe/Mono</li> <li>Windows</li> <li>100min (HDD)</li> <li>5.7W (HDD)</li> <li>DZ-BP14S</li> <li>Li-ion 1360mAh</li> <li>AC adaptor/charger</li> <li>CD-ROM (ImageMixer 3 HD Edition for BD)</li> </ul>
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES Battery pack AC adaptor USB PC Cable HDMI Cable PC software Shoulder strap AC power cord DC power cord AV cable	<ul> <li>(1920 x 1080)/(640 x 360)</li> <li>1-Second Quick Start (1 sec*)</li> <li>-/-</li> <li>SD</li> <li>English/French/Spanish/Italy/German/Chinese</li> <li>White/Wipe/Mono</li> <li>Windows</li> <li>100min (HDD)</li> <li>5.7W (HDD)</li> <li>DZ-BP14S</li> <li>Li-ion 1360mAh</li> <li>AC adaptor/charger</li> <li>CD-ROM (ImageMixer 3 HD Edition for BD)</li> </ul>
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES Battery pack AC adaptor USB PC Cable HDMI Cable PC software Shoulder strap AC power cord DC power cord AV cable Lens cap	<ul> <li>(1920 x 1080)/(640 x 360)</li> <li>1-Second Quick Start (1 sec*)</li> <li>-/-</li> <li>SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows</li> <li>100min (HDD)</li> <li>5.7W (HDD)</li> <li>DZ-BP14S</li> <li>Li-ion 1360mAh AC adaptor/charger</li> <li>CD-ROM (ImageMixer 3 HD Edition for BD)</li> <li>Multi connector W/S terminal</li> </ul>
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES Battery pack AC adaptor USB PC Cable HDMI Cable PC software Shoulder strap AC power cord DC power cord AV cable Lens cap Instruction manual	<ul> <li>(1920 x 1080)/(640 x 360)</li> <li>1-Second Quick Start (1 sec*)</li> <li>/-</li> <li>SD</li> <li>English/French/Spanish/Italy/German/Chinese</li> <li>White/Wipe/Mono</li> <li>Windows</li> <li>100min (HDD)</li> <li>5.7W (HDD)</li> <li>DZ-BP14S</li> </ul> Li-ion 1360mAh AC adaptor/charger CD-ROIM (ImageMixer 3 HD Edition for BD) Multi connector W/S terminal
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery AC adaptor USB PC Cable HDMI Cable PC software Shoulder strap AC power cord DC power cord AV cable Lens cap Instruction manual Quick guide	<ul> <li>(1920 x 1080)/(640 x 360)</li> <li>1-Second Quick Start (1 sec*)</li> <li>-/-</li> <li>SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows</li> <li>100min (HDD)</li> <li>5.7W (HDD)</li> <li>DZ-BP14S</li> <li>Li-ion 1360mAh AC adaptor/charger</li> <li>CD-ROM (ImageMixer 3 HD Edition for BD)</li> <li>Multi connector W/S terminal</li> </ul>
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES Battery pack AC adaptor USB PC Cable HDMI Cable PC software Shoulder strap AC power cord DC power cord AV cable Lens cap Instruction manual Quick guide Battery for remote	<ul> <li>(1920 x 1080)/(640 x 360)</li> <li>1-Second Quick Start (1 sec*)</li> <li>/-</li> <li>SD</li> <li>English/French/Spanish/Italy/German/Chinese</li> <li>White/Wipe/Mono</li> <li>Windows</li> <li>100min (HDD)</li> <li>5.7W (HDD)</li> <li>DZ-BP14S</li> </ul> Li-ion 1360mAh AC adaptor/charger CD-ROIM (ImageMixer 3 HD Edition for BD) Multi connector W/S terminal
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery AC adaptor USB PC Cable HDMI Cable PC software Shoulder strap AC power cord DC power cord AV cable Lens cap Instruction manual Quick guide	<ul> <li>(1920 x 1080)/(640 x 360)</li> <li>1-Second Quick Start (1 sec*)</li> <li>-/-</li> <li>SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows</li> <li>100min (HDD)</li> <li>5.7W (HDD)</li> <li>DZ-BP14S</li> <li>Li-ion 1360mAh AC adaptor/charger</li> <li>CD-ROM (ImageMixer 3 HD Edition for BD)</li> <li>Multi connector W/S terminal</li> </ul>
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES Battery pack AC adaptor USB PC Cable HDMI Cable PC software Shoulder strap AC power cord DC power cord AV cable Lens cap Instruction manual Quick guide Battery for remote Remote controller BD-RE disc	<ul> <li>(1920 x 1080)/(640 x 360)</li> <li>1-Second Quick Start (1 sec*)</li> <li>-/-</li> <li>SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows</li> <li>100min (HDD)</li> <li>5.7W (HDD)</li> <li>DZ-BP14S</li> <li>Li-ion 1360mAh AC adaptor/charger</li> <li>CD-ROIM (ImageMixer 3 HD Edition for BD)</li> <li>Multi connector W/S terminal</li> </ul>
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES Battery pack AC adaptor USB PC Cable HDMI Cable PC software Shoulder strap AC power cord DC power cord AV cable Lens cap Instruction manual Ouick guide Battery for remote Remote controller BD-RE disc PHYSICAL	<ul> <li>(1920 x 1080)/(640 x 360)</li> <li>1-Second Quick Start (1 sec*)</li> <li>-/-</li> <li>SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows</li> <li>100min (HDD)</li> <li>5.7W (HDD)</li> <li>DZ-BP14S</li> <li>Li-ion 1360mAh AC adaptor/charger</li> <li>CD-ROIM (ImageMixer 3 HD Edition for BD)</li> <li>Multi connector W/S terminal</li> </ul>
DCF Photo capture Movie to JPEG from HDD and BD/DVD Start-up time Connectivity AV/S output AV input USB 2.0 output HDMI Output Finalise button Full Auto Button Memory card slot Display language text Scene Transitions PC software Battery life** (w/o LCD) Power consumption (w/o LCD) Supplied battery ACCESSORIES Battery pack AC adaptor USB PC Cable HDMI Cable PC software Shoulder strap AC power cord DC power cord AV cable Lens cap Instruction manual Quick guide Battery for remote Remote controller BD-RE disc	<ul> <li>(1920 x 1080)/(640 x 360)</li> <li>1-Second Quick Start (1 sec*)</li> <li>-/-</li> <li>SD English/French/Spanish/Italy/German/Chinese White/Wipe/Mono Windows</li> <li>100min (HDD)</li> <li>5.7W (HDD)</li> <li>DZ-BP14S</li> <li>Li-ion 1360mAh AC adaptor/charger</li> <li>CD-ROIM (ImageMixer 3 HD Edition for BD)</li> <li>Multi connector W/S terminal</li> </ul>

HITACHI DIGITAL MEDIA, Hitachi Europe Ltd, Whitebrook Park, Lower Cookham Road, Maidenhead, Berkshire SL6 8YA UNITED KINGDOM Tel: +44 (0)1628 585 000 Fax:+44 (0)1628 585 500 www.hitachidigitalmedia.com

The specification above and photography is for reference only and may be subject to change.

<sup>11</sup> Using restart mode <sup>\*\*</sup>HX mode recording <sup>\*</sup>Using restart mode <sup>\*\*</sup>HX mode recording <sup>1</sup>, 53 Megapixel CMOS Image Sensor was developed by AltaSens, Inc. (Thousand Oaks, CA) in close work with Hitachi. All rights belong to AltaSens, Inc. 2. Microsoft® and Windows® are registered trademarks of trademark of Microsoft corporation in USA and/or other countries. 3. HDMI, HDMI logo, High-Definition Multimedia Interface are registered trademarks of trademarks of trademarks, registered trademarks, or trade names of their respective holders.